

Accessories

For outdoor applications

PIR Sensor



- Sensor to detect motion in correlation with daylight level
- Including remote control to adapt sensor settings
- Earth spike included, suitable for wall-mounting
- Reliable on/off function thanks to infrared technology
- Ambient temperature: -20 to +40 °C
- Switching load: 800W
- Connection via THORNeco cable system or adaptor with open leads (included)
- Compatible with THORNeco cable system


Ordering guide

Description	Cat Number
ECO PIR SENSOR	ECOPIR

Controllability

Time	10 s, 90 s, 5 min, 10 min, 15 min, 20 min, 30 min
lux	10 lux, 50 lux, 100 lux, 200 lux, 500 lux, 1000 lux, 2000 lux

Detection range



Photocell




- Detection of daylight/brightness level
- Switch to determine on which brightness level lights should turn on
- Earth spike included, suitable for wall-mounting
- Ambient temperature: -20 to +40 °C
- Switching load: 200W
- Connection via THORNeco cable system or adaptor with open leads (included)
- Compatible with THORNeco cable system

Ordering guide

Description	Cat Number
ECO PC SENSOR	ECOPCELL

PIR Sensor/ Photocell:




Conny IP68 Connector



- Quick connector 3 pole
- Suitable for outside and inground use
- Cable diameter 6.5 - 12 mm
- Rated cross-section rigid, single and fine stranded 1 - 2.5 mm²

Ordering guide

Description	Cat Number
CONNYP68 QUICK CONNECTOR 16A 3-POL	CONIPCON



Accessories

For outdoor applications

Cables & Connectors



IP68

- 3 pole
- High mechanical strength
- Flexible cable H07RN-F 3G 1.5 mm²
- Cable suitable for outside and inground use


Ordering guide

Description	Cat Number
ECO EXTENSION CABLE 1M	ECOEXTC1M
ECO EXTENSION CABLE 2M	ECOEXTC2M
ECO EXTENSION CABLE 5M	ECOEXTC5M
ECO EXTENSION CABLE 10M	ECOEXTC10M
ECO MAINS ADAPTOR	ECOMAINSAD
ECO EXT INTEGRATOR	ECOEXTINT
ECO T-CONNECTOR	ECOTCON
ECO MULTICONNECTOR	ECOMULTICON




Extension cable

with Male/Female connector in different lengths (1m, 2m, 5m, 10m)




Mains adaptor

Connects luminaires of the THORNeco cable system to mains (one side: Conny connector, other side: Female)





External integrator

Connects luminaires of other suppliers to the THORNeco cable system (one side: Male, other side: Conny connector)



T-Connector

for extension (1 Male, 2 Female)



Multiconnector

for extension (1 Male, 6 Female including protection caps)

